


# ORKA

## Spare parts list

### Floor saw



	<b>MASKINSALG</b> A/S UTSTYR FOR INDUSTRI OG ANLEGG Blindheimsveien 1, 5131 Nyborg <a href="http://www.maskinsalg.com">www.maskinsalg.com</a> SALG - SERVICE - UMLEIE Tlf. 55 19 96 20
---	--

# Contents

<b>General information .....</b>	<b>3</b>
<b>Spare parts list .....</b>	<b>4</b>
<b>Engine spare parts .....</b>	<b>11</b>
Gasoline Orka .....	11
Diesel Orka .....	11
<b>Maintenance kits .....</b>	<b>11</b>

# General information

This spare parts list applies to the following:

Part number	Description
4812 0510 07	Gasoline Floor saw ORKA
4812 0510 08	Diesel Floor saw ORKA
4812 0510 09	Gasoline Floor saw ORKA without engine

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

## Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.


For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!


# Spare parts list

No.	Description	Remark	Quantity		Part number
			ORKA Gasoline	ORKA Diesel	
1	Terminal		2	-	4700 1856 45
2	Clamp		5	5	4700 1865 80
3	Electric cable		1.45 m	-	4700 3641 19
4	Switch		1	-	4700 3647 63
5	Membrane		1	-	4700 3647 65
6	Washer		1	-	4700 3647 66
7	ON/OFF Plate		1	-	4700 3655 38
8	Decal		1	1	4700 3683 12
10	Adjusting bar		1	1	4812 0510 14
11	Handle		1	1	4700 3688 58
12	Screw		1	1	4700 3688 60
13	Bearing		1	1	4700 3688 61
13a	Bearing end stop		1	1	4700 1379 24
14	Angle bar		1	1	4812 0510 17
15	Handle		1	1	4700 3688 66
16	Guide		1	1	4812 0510 18
17	Throttle cable		1	-	4700 3688 71
17	Throttle cable		-	2	4700 1172 82
18	Lever		1	1	4700 3688 76
19	Screw		2	2	4700 5000 13
20	Screw		1	1	4700 5000 25
21	Screw		3	3	4700 5000 29
22	Screw		5	5	4700 5000 48
24	Screw		2	2	4700 5350 08
25	Screw		5	5	4700 5415 39
26	Nut		3	3	4700 5700 06
27	Nut		2	2	4700 5860 01
28	Nut		2	2	4700 5860 02
29	Nut		1	1	4700 5860 03
30	Nut		4	-	4700 5860 18
30	Nut		-	4	4700 5860 12
31	Washer		4	4	4700 6000 04

No.	Description	Remark	Quantity		Part number
			ORKA Gasoline	ORKA Diesel	
32	Washer		1	1	4700 6000 06
33	Washer		6	6	4700 6000 07
34	Washer		2	2	4700 6000 08
35	Washer		2	4	4700 6150 41
36	Washer		4	2	4700 6150 44
37	Pin		1	1	4700 6290 20
38	Cable tie holder		5	5	4700 9216 93
39	Terminal		1	-	4700 9600 66
40	Terminal		1	-	4700 9600 69
42	Throttle lever		1	2	4700 3684 34
43	Nipple		1	2	4700 3684 33
44	Flat spanner		1	1	470W 2095 47
47	Frame		1	-	4812 0510 11
47	Frame		-	1	4812 0510 27
48	Cover holder		1	1	4812 0510 20
49	Handle		2	2	4812 0512 91
50	Screw		1	-	4700 5000 33
50	Screw		-	1	4700 5002 96
51	Washer		2	2	4700 6000 11
52	Decal	ON - OFF	-	1	4700 3686 95
53	Screw		-	2	4812 0503 25
54	Decal		1	1	4700 3689 28
55	Decal	Noise	1	-	4700 3692 28
55	Decal	Noise	-	1	4812 0507 55
56	Decal	Atlas Copco	2	2	4812 0510 25
57	Right plastron		1	1	4812 0510 22
58	Left plastron		1	1	4812 0510 23
59	Screw		10	10	0147 3000 33
60	Nut		8	8	4700 5860 02
61	Decal	Warnings	1	1	4700 3689 29
62	Round		1	1	4812 0512 87
63	Rivet		1	1	4700 1859 96
64	Dataplate		1	1	4812 0507 87




No.	Description	Remark	Quantity		Part number
			ORKA Gasoline	ORKA Diesel	
1	Key		1	1	4700 3501 11
2	Motor shaft pulley		1	1	4700 3688 18
3	Blade shaft pulley		1	1	4700 3688 19
4	Engine	Honda GX390UT1 QWA4 SD	1	-	4700 3688 45
4	Engine	Lombardini 15LD350	-	1	4700 3696 74
5	Bearing		2	2	4700 3688 46
6	Blade shaft		1	1	4700 3688 47
7	Blade holder		1	1	4700 3688 48
8	Pin		1	1	4700 3688 49
9	Flange		1	1	4700 3688 50
10	Tensioning plate		1	-	4812 0510 13
10	Tensioning plate		-	1	4812 0510 28
11	Belt		1	-	4700 3688 62
11	Belt		-	1	4700 3696 77
12	Screw		1	1	4700 3688 65
13	Pulley cover		1	-	4812 0510 19
13	Pulley cover		-	1	4812 0510 29
14	Screw		4	4	4700 5000 37
15	Screw		1	1	0147 3000 15
16	Screw		4	4	4700 5160 02
17	Nut		4	4	4700 5860 18
18	Nut		4	4	4700 5860 19
19	Washer		4	4	4700 6150 44
20	Washer		4	4	4700 6150 45
21	Pin		1	1	4700 6290 24





No.	Description	Remark	Quantity		Part number
			ORKA Gasoline	ORKA Diesel	
1	Retaining ring		2	2	4700 1833 38
2	Retaining ring		2	2	4700 1833 39
3	Nut		2	2	4700 1835 57
4	Clamp		1	1	4700 8140 71
5	Decal	ORKA	1	1	4812 0510 26
6	Wheel		2	2	4700 3688 34
7	Wheel		2	2	4700 3688 35
8	Frame		1	1	4812 0510 12
9	Water tank		1	1	4700 3688 51
10	Tank plug		1	1	4700 3688 52
11	Flat bar		2	2	4812 0510 16
12	Flat bar		1	1	4700 3688 67
13	Rubber guard		1	1	4700 3688 68
14	Blade cover		1	1	4812 0510 15
15	Coupling		1	1	4700 3689 15
16	Water cock		1	1	4700 3689 16
17	Water coupling		1	1	4700 3689 17
18	Nipple		1	1	4700 3689 18
19	Fork		1	1	4700 3689 26
24	Nut		1	1	4700 3689 32
25	Nipple		1	1	4700 1172 81
26	Hose		1	1	4700 3689 35
27	Screw		1	1	4700 5000 34
28	Screw		1	1	4700 5000 40
29	Screw		1	1	0147 3000 15
30	Screw		2	2	4700 5330 12
31	Nut		1	1	4700 5860 02
32	Nut		1	1	4700 5860 18
33	Washer		2	2	4700 6000 02
34	Washer		1	1	4700 6000 07
35	Washer		4	4	4700 6000 14
36	Washer		1	1	4700 6040 03
37	Washer		1	1	4700 6150 44

No.	Description	Remark	Quantity		Part number
			ORKA Gasoline	ORKA Diesel	
38	Flat spanner		1	1	470W 2095 47
39	Washer		4	4	4700 W511 80
40	Screw		2	2	4700 3678 20
41	Screw		2	2	4700 5000 48
42	Nut		1	1	4700 5700 06
43	Oring		1	1	4700 1603 05
44	Decal	Arrow	1	1	4812 0503 26
45	Decal	Water only	1	1	4700 3694 24



# Engine spare parts

## Gasoline Orka

No.	Description	Remark	Quantity	Part number
1	Air filter		1	4700 3667 78
2	Fuel filter		1	4700 3671 24
3	Spark plug		1	4700 3612 42
4	Air filter cover		1	4700 1171 24
5	Stop switch		1	4700 1172 52
6	Oil alert unit		1	4812 0505 35

## Diesel Orka

No.	Description	Remark	Quantity	Part number
1	Air filter		1	4700 3699 76
2	Oil filter		1	4700 3699 82
4	Fuel filter		1	4700 3699 90

## Maintenance kits

For Orka Diesel, the throttle control kit 4812 0502 29 includes:

No.	Description	Remark	Quantity	Part number
1	Holder		1	4812 0502 30
2	Stop		1	4812 0502 31
3	Clamp		5	4700 1865 80
4	Decal		1	4700 3683 12
5	Throttle cable		1	4700 1172 82
6	Screw		2	4700 5350 08
7	Cable tie holder		5	4700 9216 93
8	Throttle lever		1	D604 0017 39
9	Nipple		1	D604 0027 30
10	Nut		2	4700 5860 01
11	Washer		2	4700 6150 41
12	Cable stop		1	4812 0502 32
13	Screw		5	4700 5415 39





**MASKINSALG** <sup>A/S</sup>  
UTSTYR FOR INDUSTRI OG ANLEGG  
Blindheimsveien 1, 5131 Nyborg  
[www.maskinsalg.com](http://www.maskinsalg.com)  
SALG - SERVICE - UMLEIE Tlf. 55 19 96 20

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.



[www.atlascopco.com](http://www.atlascopco.com)